



ARC-19821,19822 DVR - Search, Backup & Playback Instructions

The SanDisk(4GB USB2.0) and Dane-Elec(512MB USB1.0) USB drives are tested and recommended.

SEARCH - DVR CONTROL PANEL

- Press PLAY, select Event listing using the up/down buttons and press PLAY again
- To stop while playing, press STOP

BACKUP - DVR CONTROL PANEL

- Insert a USB drive to the back of DVR
- Press MENU, select USB DEVICE SETTING and press ENTER (using ► button)
- Select FORMAT/ERASE and press ENTER
- Input PASSWORD (111111 by default using ▲ button)
- Select COPY and press ENTER
- Input Day, Begin Time and End Time
- Select COPY, press ENTER and press ENTER again
- Wait until you see "100% COPIED"
- Press MENU to exit and unplug the USB drive

PLAYBACK - COMPUTER

- Insert the original DVR software CD to the computer
- Open the SOFTWARE folder, drag "Viewer_4Channel_2.0.4.exe" file and drop to PC Desktop
- Insert a USB Drive to the Computer
- Double click "Viewer_4Channel_2.0.4.exe". (The video will be automatically detected and play)

CONVERT VIDEO TO MYS FILE - COMPUTER

Backup:

- The video file from the USB drive can be converted to MYS file only. (AVI file can be recorded through the IE web browser only)
- While playing the video clip from the PC Viewer, click Pause
- On the Menu Toolbar, select "Capture > Capture MYS"
- When complete click Stop Capturing and a MYS file will be created and save on PC Desktop
- A MYS Message Box will popup and indicate "An MYS file was created" then click OK
- The MYS file can be transferred to any folder or burn to any USB/CD-R/CD-RW/DVD-R/DVD-RW disk
- The MYS file can be play with the original PC Viewer only. (We strongly recommended you to burn the player with the video clip together)

Playback:

- Double click "Viewer_4Channel_2.0.4.exe" to open the PC Viewer
- You will see "Detection Error" message if your USB drive with the video clip is unplug. Click OK to ignore it.
- By default the PC Viewer will become a MYS Player
- On the Menu Toolbar, select "MYS Player > Load MYS File"
- Locate the MYS file video and click Open

RECORD VIDEO TO AVI FILE - IE WEB BROWSER

Backup:

- AVI file can be recorded through the IE web browser only
- Open an IE web browser, type the IP or domain in the address bar and press Enter
- Login with your User Name and Password (admin/1234 by default)
- Select and enlarge any channel or keep all channels for recording
- Click Record, check "Save as AVI" box and click OK
- A red color dot will appear at the lower right side of the screen
- To stop click Record again and click OK on a small popup window

Playback:

- By default the AVI file video will be saved on PC Desktop
- Double click the AVI file and it will be playing with Microsoft Media Player