



ARC-1IP2280D(W) – IP Cam Easy Setup Guide

1. Router Connection

- Connect IP cam with router using the Ethernet cable.
- Power on both IP cam and router.

2. Network Setup

- Install IP cam software that came with the package (double click on the file name "**IP CAM Search Software Setup.exe**" and follow the indtruction)
- Open "**IP PT CAM Discoverer**" program
- Click Configure, check "DHCP", type "admin" for Admin Password and click OK
- When a dialog box appears, type default username/password: admin/admin
- On the control panel, click Configuration and System Settings
- On the DIS Settings, check "On" for DIS and click Apply

3. DIS Register

- Open Internet Explore and go to <http://dis.wprosoft.com>
- Enter your DIS ID/password which is included on DIS license card that came with the package
- Click Agree to the Terms of Service
- Fill in the Personal Setup form and click OK
- Re-login, select Channel and install ActiveX in the browser.
- Re-login, finish ActiveX installation and you are set.