



PTZ Camera	18330 Controller Security System Control	18332 Controller System Controller	18336 Controller Hi-Speed PTZ Controller	18338 Controller PTZ & Multiplexer
<p>12E00, 12E03A, 12E03B Dip Switch SW1: 1 on (ID) SW2: 1 on (Pelco) (all off = Native) SW3: all off (9600)</p> <p>12E02A, 12E02B Dip Switch SW1: 1 on (ID) SW2: 5 on (Pelco)</p> <p><i>Make sure to unplug the power cable and power up after changing the dip switch.</i></p> <p><i>For advance feature, please read the user manual.</i></p>	<p>Setup - Press MENU - Enter Password - Keyboard ID: 01 - Operation Mode: Pelco D - Comm Parameter: 9600,N,8,1</p> <p>Preset Point Setup - Enter preset no. (1~32, 35~82) - Press SET PRESET - To enter press SET PRESET</p> <p>Call Preset Point - Enter preset no. (1~32, 35~82) - Press GO PRESET</p> <p>Auto Scan - Enter no. 99 - Press GO PRESET - To stop: push joystick to any direction</p> <p>Pattern Run Mode (Auto Pan) - Enter group no. (1~6) - Press PATTERN - To stop: push joystick to any direction</p> <p>Enter Camera's Main Menu - Press F2 or enter no. 95 - Upward: NEAR or joystick - Downward: FAR or joystick - To save: press OPEN - To leave: press CLOSE # Dwell time: select Autopan & Dwell Time</p>	<p>Setup Automatically detected if the PTZ's SW2 set to Native protocol (all off) (Yoko PTZ only)</p> <p>Preset Point Setup - Enter number - Press SET PRESET - To save SET PRESET</p> <p>Call Preset Point - Enter number - Press GO PRESET</p> <p>Cruise Track (Auto Pan) - Enter group number - Press AUTO PAN - To stop: push joystick to any direction</p> <p>Enter Camera's Main Menu - Press MENU - Upward: UP ARROW - Downward: DOWN ARROW - To save: press ENTER - To leave: press ESC # Dwell time (Yoko PTZ only) press Left/Right Arrow key</p>	<p>Setup Adjust the ID Code Protocol: 1 on (ID) Protocol: 2 on (Pelco) Baud Rate: 6 on (9600) Not Used: the rest off</p> <p>Preset Point Setup - Enter no. 1~64 - Press PRESET</p> <p>Call Preset Point - Enter no. 1~64 - Press CALL</p>	<p>Setup Adjust the ID Code Protocol: 1 on (ID) Protocol: 2 on (Pelco) Baud Rate: 6 on (9600) Not Used: the rest off</p> <p>Preset Point Setup - Press PRESET - Enter no. (1~128) - Press ENTER</p> <p>Call Preset Point - Press CALL & enter no 1-128 - Press ENTER</p> <p>Auto Scan - Press CALL & enter no. 99 - Press ENTER - To stop: push joystick to any direction</p> <p>Cruise Track (Auto Pan) - Press AUTO & enter no. 1~6 - Press ENTER - To stop: push joystick to any direction</p> <p>Enter Camera's Main Menu - Press SHOT & enter no. 1~6 - Next page: TELE - Up page: WIDE - To save: press OFF - To leave: push joystick to any direction # Dwell time: select Time & enter no.</p>